



**INSTALLATION INSTRUCTIONS**

1. CHOOSE APPROPRIATE MOUNTING HARDWARE (MOUNTING PLATES OR TRACK.) ALL HARDWARE MUST BE ATTACHED TO STRUCTURAL MEMBERS, FLOOR AND CEILING. USE THREAD LOCK ONLY WHERE INDICATED, DO NOT APPLY ON RESIN PANEL.
2. ATTACH BARRELS TO MOUNTING HARDWARE WITH MOUNT BARREL SCREW.
3. INSERT CABLE INTO CEILING MOUNT BARREL AND TIGHTEN 3MM ALLEN SET SCREW TO SECURE.
4. CUT CABLE TO 1/8" (3MM) ABOVE FULLY EXTENDED FLOOR MOUNT BARREL.
5. SLIDE FLOOR MOUNT SLEEVE AND SPRING ONTO CABLE. ATTACH BRASS FERRULE ONTO THE END OF CABLE USING 2MM ALLEN SET SCREWS.
6. SCREW FLOOR MOUNT SLEEVE ONTO FLOOR MOUNT BARREL.
7. ATTACH PANELS USING APPROPRIATE SINGLE OR DOUBLE PANEL CONNECTORS POSITIONED 1.5" (35MM) FROM THE TOP AND BOTTOM OF PANELS. MAXIMUM 24" (610MM) BETWEEN PANEL CONNECTORS. USING A 3MM ALLEN WRENCH, TIGHTEN THE SET SCREW UNTIL THE NYLON TIP MAKES CONTACT WITH THE PANEL, THEN CONTINUE TO TIGHTEN THREE-QUARTERS TO ONE FULL TURN. DO NOT OVER TIGHTEN THE SET SCREW, THIS CAN DAMAGE BOTH THE FINISH OF THE PANEL AND THE PANEL CLIP.



	<p><b>CABLE PARTITION</b> 404.00   Installation Instructions</p> <p>These drawings have not been reviewed and approved by the architect and cannot ever be used for construction purposes. These drawings are for the exclusive use of Lumicor. Any use of these drawings by others will be at their own risk and lumicor will not be responsible for issues that may arise from their use.</p> <p>© Lumicor 2019 — All Rights Reserved. For more information, visit <a href="http://www.lumicor.com">www.lumicor.com</a> or call 1.888.LUMICOR (888.586.4267)</p>	<p>Solution 404.00</p> <hr/> <p>12/23/19</p> <hr/> <p>Page 2 of 2</p>
---	--	---