

INSTALLATION INSTRUCTIONS

- USING A ¹/₂" MASONRY BIT, DRILL TO A MINIMUM 1 DEPTH OF 6" THROUGH THE BOTTOM OF YOUR MOUNT.
- 2. THREAD THE ANCHOR THROUGH THE BASE OF THE MOUNT SECURING IT TO YOUR SUBSTRATE.
- 3 TEMPORARILY PLACE ONE POST OVER THE MOUNTING BASE AND FASTEN THE 3 BUTTON HEAD SCREWS FROM THE OUTSIDE. BE SURE TO ALIGN YOUR GRIPPER HOLES THE DIRECTION THE PANEL IS TO BE INSTALLED.
- USING THE TEMPORARILY PLACES POST, MOUNT 4. **GRIPPERS PROVIDED TO THE POST AT THE** PREDRILLED LOCATIONS.
- 5. ALIGN WALL GRIPPER LOCATIONS WITH THE **GRIPPERS ALONG THE POST.**
- REMOVE THE FREE STANDING POST WHILE 6. INSTALLING THE PANEL TO THE WALL.
- INSTALL THE PANEL TO THE WALL MOUNTED 7. GRIPPERS. USE THE CUP POINT SET SCREW THROUGH THE LUMICOR PANEL.
- SUPPORT THE LUMICOR PANEL WHILE THE POST IS 8. MOUNTED TO IT'S MOUNTING PLATE. SCREW THE 3 BASE SCREWS FROM THE OUTSIDE OF THE POST TO IT'S BASE.
- 9. SCREW IN THE CUP POINT SCREWS THROUGH THE PANEL ON THE SECOND SET OF GRIPPERS.
- 10. FINISH BY INSERTING THE TOP CAPS TO ALL POSTS.






responsible for issues that may arise from their use.

409.00 | Installation Instructions

Page 2 of 2



© Lumicor 2019 – All Rights Reserved. For more information, visit www.lumicor.com or call 1.888.LUMICOR (888.586.4267)